



How to replace the Rivets in your Roros fridge

1. First take the door panel off (screws should be located on the inside of the door).
 2. Open the door and unscrew the screws on the top hinge - the door will not be attached to the roof now so don't let go of the door.
 3. Close the door and undo the bottom bolt - use 13mm spanner.
 4. Lift the door off and place it on its side (edge) - make sure the hinge is not on the floor.
 5. Start drilling out the old rivets (Drill and Drill Bit for Steel).
 6. When you have taken the hinge out you should find two metal spacers, they need to go back in.
 7. Take the hinge and place it in the slot. The two spacers need to go back in at the same time as putting the rivets in. They go between the metal of the door and the hinge, the rivets have to slot into the spacers and then the hinge.
 8. Place rivet gun over the rivet and compress the gun several times until the thin piece of the rivet breaks off. Repeat this on the other rivet, the hinge should now be tight.
-